

PROGRAMMABLE SENSOR OVERRIDE	Hold - , turn to Start Times
CYCLE AND SOAK	Hold + , turn to Run Times Press PRG to set Soak
DELAY BETWEEN STATIONS	Hold - , turn to Run Times
HIDE PROGRAMS	Hold - , turn to Water Days
TEST PROGRAM	Hold PRG for 3 seconds

Feature	Where Found
TOTAL RUN TIME	Turn to Run Times Press ◀ from Station 1 to view Press PRG to select program
EASY RETRIEVE™	Press + and PRG to Save Press - and PRG to Restore
TOTAL RESET	Press PRG and RESET button
QUICK CHECK™	Press + - , ◀ , ▶ together Press + to begin check
RUN PROGRAM	Hold ▶ , press PRG to select